

Outdoor button IP 44

CODE: SC.2103

Outdoor transmitter buttons complete with battery button 3V - CR2032

Colour: polar white

To be used with chimes AS.14 - AS.309 - AS.328 - AS.335 - AS.5001 - AS.3007 - AS.2309

